

# Easy Harmony XB2 metal pushbuttons



## Selector switches (1)

|   |                       |          |          |          |          |          |          |          |
|---|-----------------------|----------|----------|----------|----------|----------|----------|----------|
| <b>Positions</b>                              | 2                     | 2        | 3        | 3        | 2        |          |          |          |
| <b>Contact</b>                                | NO                    | NO + NC  | NO       | NO + NC  | 2 NO     |          |          |          |
| <b>Connection</b>                             | Screw clamp terminals |          |          |          |          |          |          |          |
| <b>Complete product for standard mounting</b> | 1 Standard handle     | XB2BD21C | XB2BD25C | XB2BD41C | XB2BD45C | XB2BD33C | XB2BD53C | XB2BD73C |
|   | 2 Long handle         | XB2BJ21C | XB2BJ25C | -        | -        | XB2BJ33C | XB2BJ53C | -        |

## 3 Key switches (No. 455) (1)

|   |                       |          |          |          |          |          |          |
|---|-----------------------|----------|----------|----------|----------|----------|----------|
| <b>Positions</b>                              | 2                     | 2        | 2        | 3        | 3        | 3        |          |
| <b>Connection</b>                             | Screw clamp terminals |          |          |          |          |          |          |
| <b>Complete product for standard mounting</b> | NO                    | XB2BG21C | XB2BG41C | XB2BG61C | -        | -        | -        |
|   | 2 NO                  | -        | -        | -        | XB2BG33C | XB2BG53C | XB2BG03C |
|   | NO + NC               | XB2BG25C | XB2BG45C | XB2BG65C | -        | -        | -        |



## Illuminated pushbuttons with integral LED (1)

|   |                       |            |            |            |            |            |
|---|-----------------------|------------|------------|------------|------------|------------|
| <b>Color</b>                                  | White                 | Green      | Red        | Yellow     | Blue       |            |
| <b>Contact</b>                                | NO                    |            |            |            |            |            |
| <b>Connection</b>                             | Screw clamp terminals |            |            |            |            |            |
| <b>Complete product for standard mounting</b> | 1 24 V AC/DC          | XB2BW31B1C | XB2BW33B1C | XB2BW34B1C | XB2BW35B1C | XB2BW36B1C |
|   | 2 220...230 V AC      | XB2BW31M1C | XB2BW33M1C | XB2BW34M1C | XB2BW35M1C | XB2BW36M1C |



## Joysticks

|                     |               |           |
|---------------------|---------------|-----------|
| <b>Return type</b>  | Spring return | Stay      |
| <b>2 Directions</b> | XD2PA22CR     | XD2PA12CR |
| <b>4 Directions</b> | XD2PA24CR     | XD2PA14CR |



## Buzzers

|                        |                   |               |
|------------------------|-------------------|---------------|
| <b>Characteristics</b> | Non-illuminated 1 | Illuminated 2 |
| 24 V AC/DC             | XB2BSBC           | XB2BSB4LC     |
| 220...230 V AC         | XB2BSMC           | XB2BSM4LC     |

(1) This product line will be available starting in Q3 2023.

**Note:** For illuminated pilot lights, please refer to Easy Harmony XA2 range.